Publication No. IP 3066
3/95

PARTS LIST

for the

KODAK MULTILOADER 700 SIDE-BY-SIDE KIT



© KODAK AG Stuttgart, 1995

NOTE

Due to safety regulations only original parts must be used in case of replacement.

PLEASE NOTE

The information contained herein is based on the experience and knowledge relating to the subject matter gained by Kodak prior to publication. No patent license is granted by this information. Kodak reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from the use of this information, even if loss or damage is caused by Kodak's negligence or other fault.

Section Page

CHAPTER 1 1-1

FILM TRANSPORT SYSTEM 1-1

CHAPTER 2 2-1

ADAPTER 460/480RA / M6B / M6AW 2-1

CHAPTER 3 3-1

ELECTRONICS 3-1

CHAPTER 4 4-1

PROCESSOR REMOTE ON/OFF 4-1

CHAPTER 5 5-1

DARK ROOM FEED TRAY (DFT) 5-1

CHAPTER 6 6-1

PANELS 6-1

NUMERICAL INDEX N-1

ALPHABETICAL INDEX A-1

CHAPTER 1
SIDE-BY-SIDE KIT



figure 1-1

PARTS LISTING figure 1-1

ITEM No.	PART No.	PART NAME	QUANTITY
1	9260826	ROLLER SHAFT	2
2	9260816	PRESSURE ROLLER	2
3	9260856	SPACER SHAFT	1
4	9260806	BELT	6
5	9227010	BALL BEARING	10
6	9260276	ROLLER with O-RING	1
7	4283521	COUNTERSUNK SCREW	1
8	4283126	SCREW M4 x 10	8
9	9260606	CLUTCH DISK	2
10	5559519	PIN	2
11	9260956	SENSOR ACTUATOR RIGHT	1
12	9260916	FILM POSITIONER ASSY RIGHT	1
13	9260926	FILM POSITIONER ASSY LEFT	1
14	9260966	SENSOR ACTUATOR LEFT	1
15	9260846	CARRIAGE FRAME	1
16	4480091	WASHER	2
17	9260741	PRESSURE SPRING front right and back left	2
18	9260286	PRESSURE SPRING front left and back right	2
19	9250546	FILM GUIDE	1
20	8317366	SPACER	8
21	4500566	C-RING	8



figure 1-2

PARTS LISTING figure 1-2

ITEM No.	PART No.	PART NAME	QUANTITY
1	9260536	BRACKET	1
2	9260686	BALL BEARING	2
3	9226130	FREE RUNNING CLUTCH	1
4	9260516	CLUTCH MOUNT ASSY LEFT	1
	9260506	CLUTCH MOUNT ASSY RIGHT	1
5	9260586	SPRING DISK	1
6	9260696	CLUTCH SPRING	1
7	4500526	CIRCLIP	2
8	9260556	BOLT	1
9	9260701	KEY	2
10	9260546	CLUTCH DISK ASSY	1
11	9227010	BALL BEARING	1
12	9260661	DRIVE GEAR	1
13	9212331	WHITE PLASTIC BEARING	1
14	9260526	BRACKET	1
15	4283126	SCREW M4 x 10	4
16	9260716	TOOTHED BELT	1
17	4266540	SCREW M4 x 25	2



figure 1-3

PARTS LISTING figure 1-3

ITEM No.	PART No.	PART NAME	QUANTITY
1	9260906	ADJUSTMENT BRACKET LEFT	1
2	9261646	PHOTO SENSOR	2
3	9260976	SENSOR BRACKET	2
4	4282791	SCREW M3 x 16	8
5	4470106	WASHER	12
6	4283301	SCREW M3 x 8	4
7	9260896	ADJUSTMENT BRACKET RIGHT	1
8	9260886	MOUNTING BRACKET RIGHT	1
9	9260336	TENSION SPRING	2
10	9260076	CARRIAGE GUIDE	1
11	4281761	ADJUSTMENT SCREW	2
12	9260876	MOUNTING BRACKET LEFT	1
13	9260376	BOLT	4
14	4480176	WASHER	4
15	4500526	CIRCLIP	8



figure 1-4

PARTS LISTING figure 1-4

ITEM No.	PART No.	PART NAME	QUANTITY
1	9250176	STEPPER MOTOR M2	1
2	9260576	SHAFT	1
3	4796376	PIN	1
4	9227010	BALL BEARING	1
5	9223400	TOOTHED BELT	1
6	9260666	DRIVE GEAR	1
7	4500526	CIRCLIP	1
8	9260526	BRACKET	1
9	9212331	WHITE PLASTIC BEARING	1
10	4283126	SCREW M4 x 10	5
11	9260026	DRIVE GEAR	1
12	9260671	KEY 2x2x12	1
13	4480036	WASHER	3
14	9260626	MOTOR MOUNTING BRACKET	1
15	4283301	SCREW M3 x 8	4
16	4470106	WASHER 3.2	4



figure 1-5

PARTS LISTING figure 1-5

ITEM No.	PART No.	PART NAME	QUANTITY
1	9218016	MOTOR M1	1
2	4719346	PIN 5x14	1
3	9211836	PULLEY	1
4	4500416	RETAINING RING	1
5	4282811	SCREW M4 x 20	3
6	4283126	SCREW M4 x 10	4
7	9260866	TIMING BELT	1
8	9260616	TIMING BELT TENSIONER	1
9	4853256	NUT M4	1
10	9260721	THREADED SHAFT	1
11	9260736	PULLEY WITH BEARING	1
12	4880036	WASHER	2



figure 1-6

PARTS LISTING figure 1-6

ITEM No.	Part No.	PART NAME	QUANTITY
1	9266166	UPPER CARRIGE GUIDE ROLLER	2
2	9266168	LOWER CARRIAGE GUIDE ROLLER, eccentric	2



figure 1-7

PARTS LISTING figure 1-7

ITEM No.	PART No.	PART NAME	QUANTITY
1	9189546	REFLECTIVE FOIL	2
2	9261506	SERVICE PLATE	1

CHAPTER 2
ADAPTER 460/480RA / M6B / M6AW


The BEARING must be installed with this side up
There is a small arrow on the PULLEY. Install the PULLEY with the arrow on this side

figure 2-1

PARTS LISTING figure 2-1

ITEM No.	PART No.	PART NAME	QUANTITY
1	9263026	INPUT ROLLER TOP	1
2	9263016	INPUT ROLLER BOTTOM	1
3	9226130	PULLEY with FREE RUNNING CLUTCH	2
4	9260196	EXIT ROLLER	2
5	9260106	FRAME	1
6	9260046	MOUNTING PLATE	1
7	9223130	BEARING	2
8	9261511	SECURING PLATE	2
9	9260131	TOOTHED BELT	1
10	9227010	BALL BEARING	6
11	9260116	BASE PLATE	1
12	9260156	SHAFT	1
13	4283126	SCREW M4 x 10	13
14	9260126	ENTRANCE GUIDE	1
15	9260061	ACTUATOR	2
16	4500526	CIRCLIP	2
17	9222050	PLASTIC BEARING	2
18	9260181	BEARING	2
19	4500566	CIRCLIP	8
20	4853236	NUT M4	4
21	4283301	SCREW M3 x 8	4
22	9260226	SENSOR	2
23	9260566	GUIDE	1
24	9262796	HANDLE	1
25	4282261	COUNTERSUNK SCREW M4 x 12	2
26	9260246	EXIT GUIDE	1
27	8317366	WASHER	6
28	4480032	WASHER	3



figure 2-2

PARTS LISTING figure 2-2

ITEM No.	PART No.	PART NAME	QUANTITY
1	9250176	STEPPER MOTOR M3	1
2	4796376	PIN	1
3	9216111	DRIVE GEAR	1
4	4500526	CIRCLIP	1
5	4283301	SCREW M3 x 8	4

CHAPTER 3
ELECTRONICS


3
4
T2.5A
A1X3
T2.5A
A1X2
T 1.6 A
A1X4
T1.6A
A1X1
F3
CR3
F2
CR2
F4
F1
CR4
CR1
CAUTION
For continued protection
against the risk of fire,
replace only with a fuse of
the same type and ratins.
C3
C2
C4
C1
R1
D1
LB1
C5
C7
C6
R2
A1X6
A1X7
A1X5
T1
T2
5
2
1

figure 3-1

PARTS LISTING figure 3-1

ITEM No.	PART No.	PART NAME	QUANTITY
1	9261010	PCB A1 POWER SUPPLY	1
2	4522331	RECTIFIER	4
3	4538501	FUSE F2 F3 T2.5 A	2
4	4538511	FUSE F1 F4 T1.6A	2
5	9267616	TRANSFORMER	2



figure 3-2

PARTS LISTING figure 3-2

ITEM No.	PART No.	PART NAME	QUANTITY
1	9261020	PCB A2 RELAY BOARD	1



JUMPER SETTING

Layout Version 1

X5 **E2**

does not exist for this version

Layout Version 2

E1 **E2**



figure 3-3

PARTS LISTING figure 3-3

ITEM No.	PART No.	PART NAME	QUANTITY
1	9218510	PCB A3 SLAVE PROCESSOR without software	1
2	9263006	SOFTWARE V 1.3	1

NOTE

When installing a new PCB A3 check the JUMPER SETTING. Both Layout Versions are interchangeable.


12
S2
U9
U15
U11
U21
U8
U10
U4
U5
U3
U26
U1
U22
U2
U7
U15
U17
U20
U18
K1
R61
D5
D4
D6
D3
R55
U22
U23
U28
R76
R77
R78
U29
U24
U25
1
2

figure 3-4

PARTS LISTING figure 3-4

ITEM No.	PART No.	PART NAME	QUANTITY
1	9261000	PCB A4 FTS INTERFACE	1
2	9263346	BRIGHTNESS CONTROL PCB	1



figure 3-5

PARTS LISTING figure 3-5

ITEM No.	PART No.	PART NAME	QUANTITY
1	9228980	SENSOR B1	1
2	9263056	REED SWITCH	2
3	9263066	PERMANENT MAGNET	2
4	9261376	SERVICE BUTTON	1
5	9250186	LED GREEN/RED	1



figure 3-6

PARTS LISTING figure 3-6

ITEM No.	PART No.	PART NAME	QUANTITY
1	9261036	CABLE PROCESSOR READY (to M6/M8 Connector)	1
2	9261046	CABLE PROCESSOR START (to ME3 Connector)	1
3	9261056	CABLE TUNNEL SENSOR short	1
4	9261066	CABLE TUNNEL SENSOR long	1
5	9261166	CABLE RA-PROC	1
6	9197126	CABLE PROC. READY M6B	1
7	9192226	CABLE PROC. START M6B	1
8	9261076	CABLE PROCESSOR SAFE LIGHT RECEPTACLE	1
	6051531	POWER CORD US / CANADA / MEXICO is needed between CABLE 9261071 and the PROCESSOR SAFELIGHT RECEPTACLE as ADAPTER CABLE for M6B up to SN 20000 AND FOR 460RA up to SN 1132 and for all M6AW	1
9	9261196	FAN	1
9	9263141	AIR FILTER, FAN	1
10	9261186	IEC CONNECTOR with FUSE ASSEMBLY	1
11	4516096	FUSE 3.15A T IEC	1
11	4539881	FUSE 2.A SLOW BLOW UL/CSA	1
12	6051531	POWER CORD US / CANADA / MEXICO	1
12	6217861	POWER CORD AUSTRALIA	1
12	6217851	POWER CORD ENGLAND / IRELAND	1
12	6004060	POWER CORD FRANCE / ITALY	1
12	6037200	POWER CORD SWIZERLAND	1
12	4513990	POWER CORD REST OF EUROPE	1

CHAPTER 4
PROCESSOR REMOTE ON/OFF



figure 4-1

PARTS LISTING figure 4-1

ITEM No.	PART No.	PART NAME	QUANTITY
1	9260766	KNOB	1
2	9212051	PLASTIC BEARING	1
3	9260776	MAIN SWITCH EXTENSION	1
4	4500526	CIRCLIP	1
5	9260786	ACTUATOR	1
6	9261551	COVER PLATE (for M6B and M6AW only)	1

NOTE

Parts for the 460/480RA and M6B / M6AW PROCESSORS are the same.

CHAPTER 5
DARK ROOM FEED TRAY (DFT)



figure 5-1

PARTS LISTING figure 5-1

ITEM No.	PART No.	PART NAME	QUANTITY
1	9263066	PERMANENT MAGNET	1
2	9263056	REED SWITCH	1
3	9224410	SOLENOID	1
4	9229630	PIN ASSY	1
5	4283286	SCREW M3 x 6	2
6	4281931	SCREW M6	2
7	4283126	SCREW M4 x 10	4
8	9263316	DFT TOP COVER	1
9	9263371	LOCK PLATE	1
10	4282261	COUNTERSUNK SCREW M4 x 12	1

CHAPTER 6
PANELS



figure 6-1

PARTS LISTING figure 6-1

ITEM No.	PART No.	PART NAME	QUANTITY
1	9261546	SBS COVER	1
2	9260036	ADAPTER COVER	1
3	9263116	SIDE PANEL large	1
4	9263096	SIDE PANEL small	1

NUMERICAL INDEX

PART No.	PART NAME	FIGURE No.
4266540	SCREW M4 x 25	1-2
4281761	ADJUSTMENT SCREW	1-3
4281931	SCREW M6	5-1
4282261	COUNTERSUNK SCREW M4 x 12	2-1, 5-1
4282791	SCREW M3 x 16	1-3
4282811	SCREW M4 x 20	1-5
4283126	SCREW M4 x 10	1-1, 1-2, 1-4, 1-5, 2-1, 5-1
4283286	SCREW M3 x 6	5-1
4283301	SCREW M3 x 8	1-3, 1-4, 2-1, 2-2
4283521	COUNTERSUNK SCREW	1-1
4470106	WASHER	1-3
4470106	WASHER 3.2	1-4
4480032	WASHER	2-1
4480036	WASHER	1-4
4480091	WASHER	1-1
4480176	WASHER	1-3
4500416	RETAINING RING	1-5
4500526	CIRCLIP	1-2, 1-3, 1-4, 2-1, 2-2, 4-1
4500566	C-RING	1-1
4500566	CIRCLIP	2-1
4513990	POWER CORD REST OF EUROPE	3-6
4516096	FUSE 3.15A T IEC	3-6
4522331	RECTIFIER	3-1
4538501	FUSE F2 F3 T2.5 A	3-1
4538511	FUSE F1 F4 T1.6A	3-1
4539881	FUSE 2.A SLOW BLOW UL/CSA	3-6
4719346	PIN 5x14	1-5
4796376	PIN	1-4, 2-2
4853236	NUT M4	2-1
4853256	NUT M4	1-5
4880036	WASHER	1-5
5559519	PIN	1-1
6004060	POWER CORD FRANCE / ITALY	3-6
6037200	POWER CORD SWIZERLAND	3-6
6051531	POWER CORD US / CANADA / MEXICO	3-6
6217851	POWER CORD ENGLAND / IRELAND	3-6
6217861	POWER CORD AUSTRALIA	3-6
8317366	SPACER	1-1
8317366	WASHER	2-1
9189546	REFLECTIVE FOIL	1-7
9192226	CABLE PROC. START M6B	3-6
9197126	CABLE PROC. READY M6B	3-6
9211836	PULLEY	1-5

PART No.	PART NAME	FIGURE No.
9212051	PLASTIC BEARING	4-1
9212331	WHITE PLASTIC BEARING	1-2, 1-4
9216111	DRIVE GEAR	2-2
9218016	MOTOR M1	1-5
9218510	PCB A3 SLAVE PROCESSOR without software	3-3
9222050	PLASTIC BEARING	2-1
9223130	BEARING	2-1
9223400	TOOTHED BELT	1-4
9224410	SOLENOID	5-1
9226130	FREE RUNNING CLUTCH	1-2
9226130	PULLEY with FREE RUNNING CLUTCH	2-1
9227010	BALL BEARING	1-1, 1-2, 1-4, 2-1
9228980	SENSOR B1	3-5
9229630	PIN ASSY	5-1
9250176	STEPPER MOTOR M2	1-4
9250176	STEPPER MOTOR M3	2-2
9250186	LED GREEN/RED	3-5
9250546	FILM GUIDE	1-1
9260026	DRIVE GEAR	1-4
9260036	ADAPTER COVER	6-1
9260046	MOUNTING PLATE	2-1
9260061	ACTUATOR	2-1
9260076	CARRIAGE GUIDE	1-3
9260106	FRAME	2-1
9260116	BASE PLATE	2-1
9260126	ENTRANCE GUIDE	2-1
9260131	TOOTHED BELT	2-1
9260156	SHAFT	2-1
9260181	BEARING	2-1
9260196	EXIT ROLLER	2-1
9260226	SENSOR	2-1
9260246	EXIT GUIDE	2-1
9260276	ROLLER with O-RING	1-1
9260286	PRESSURE SPRING front left and back right	1-1
9260336	TENSION SPRING	1-3
9260376	BOLT	1-3
9260506	CLUTCH MOUNT ASSY RIGHT	1-2
9260516	CLUTCH MOUNT ASSY LEFT	1-2
9260526	BRACKET	1-2, 1-4
9260536	BRACKET	1-2
9260546	CLUTCH DISK ASSY	1-2
9260556	BOLT	1-2
9260566	GUIDE	2-1

PART No.	PART NAME	FIGURE No.

9260576 ..... SHAFT 1-4
9260586 ..... SPRING DISK 1-2
9260606 ..... CLUTCH DISK 1-1
9260616 ..... TIMING BELT TENSIONER 1-5
9260626 ..... MOTOR MOUNTING BRACKET 1-4
9260661 ..... DRIVE GEAR 1-2
9260666 ..... DRIVE GEAR 1-4
9260671 ..... KEY 2x2x12 1-4
9260686 ..... BALL BEARING 1-2
9260696 ..... CLUTCH SPRING 1-2
9260701 ..... KEY 1-2
9260716 ..... TOOTHED BELT 1-2
9260721 ..... THREADED SHAFT 1-5
9260736 ..... PULLEY WITH BEARING 1-5
9260741 ..... PRESSURE SPRING front right and back left 1-1
9260766 ..... KNOB 4-1
9260776 ..... MAIN SWITCH EXTENSION 4-1
9260786 ..... ACTUATOR 4-1
9260806 ..... BELT 1-1
9260816 ..... PRESSURE ROLLER 1-1
9260826 ..... ROLLER SHAFT 1-1
9260846 ..... CARRIAGE FRAME 1-1
9260856 ..... SPACER SHAFT 1-1
9260866 ..... TIMING BELT 1-5
9260876 ..... MOUNTING BRACKET LEFT 1-3
9260886 ..... MOUNTING BRACKET RIGHT 1-3
9260896 ..... ADJUSTMENT BRACKET RIGHT 1-3
9260906 ..... ADJUSTMENT BRACKET LEFT 1-3
9260916 ..... FILM POSITIONER ASSY RIGHT 1-1
9260926 ..... FILM POSITIONER ASSY LEFT 1-1
9260956 ..... SENSOR ACTUATOR RIGHT 1-1
9260966 ..... SENSOR ACTUATOR LEFT 1-1
9260976 ..... SENSOR BRACKET 1-3
9261000 ..... PCB A4 FTS INTERFACE 3-4
9261010 ..... PCB A1 POWER SUPPLY 3-1
9261020 ..... PCB A2 RELAY BOARD 3-2
9261036 ..... CABLE PROCESSOR READY (to M6/M8 Connector) 3-6
9261046 ..... CABLE PROCESSOR START (to ME3 Connector) 3-6
9261056 ..... CABLE TUNNEL SENSOR short 3-6
9261066 ..... CABLE TUNNEL SENSOR long 3-6
9261076 ..... CABLE PROCESSOR SAFE LIGHT RECEPTACLE 3-6
9261166 ..... CABLE RA-PROC 3-6
9261186 ..... IEC CONNECTOR with FUSE ASSEMBLY 3-6

PART No.	PART NAME	FIGURE No.
9261196	FAN	3-6
9261376	SERVICE BUTTON	3-5
9261506	SERVICE PLATE	1-7
9261511	SECURING PLATE	2-1
9261546	SBS COVER	6-1
9261551	COVER PLATE (for M6B and M6AW only)	4-1
9261646	PHOTO SENSOR	1-3
9262796	HANDLE	2-1
9263006	SOFTWARE V 1.3	3-3
9263016	INPUT ROLLER BOTTOM	2-1
9263026	INPUT ROLLER TOP	2-1
9263056	REED SWITCH	3-5, 5-1
9263066	PERMANENT MAGNET	3-5, 5-1
9263096	SIDE PANEL small	6-1
9263116	SIDE PANEL large	6-1
9263141	AIR FILTER, FAN	3-6
9263316	DFT TOP COVER	5-1
9263346	BRIGHTNESS CONTROL PCB	3-4
9263371	LOCK PLATE	5-1
9266166	UPPER CARRIGE GUIDE ROLLER	1-6
9266168	LOWER CARRIAGE GUIDE ROLLER, eccentric	1-6
9267616	TRANSFORMER	3-1

ALPHABETICAL INDEX

PART NAME	PART No.	FIGURE No.
ACTUATOR	9260061	2-1
ACTUATOR	9260786	4-1
ADAPTER COVER	9260036	6-1
ADJUSTMENT BRACKET LEFT	9260906	1-3
ADJUSTMENT BRACKET RIGHT	9260896	1-3
ADJUSTMENT SCREW	4281761	1-3
AIR FILTER, FAN	9263141	3-6
BALL BEARING	9227010	1-1, 1-2, 1-4, 2-1
BALL BEARING	9260686	1-2
BASE PLATE	9260116	2-1
BEARING	9223130	2-1
BEARING	9260181	2-1
BELT	9260806	1-1
BOLT	9260376	1-3
BOLT	9260556	1-2
BRACKET	9260526	1-2, 1-4
BRACKET	9260536	1-2
BRIGHTNESS CONTROL PCB	9263346	3-4
C-RING	4500566	1-1
CABLE PROC. READY M6B	9197126	3-6
CABLE PROC. START M6B	9192226	3-6
CABLE PROCESSOR READY (to M6/M8 Connector)	9261036	3-6
CABLE PROCESSOR SAFE LIGHT RECEPTACLE	9261076	3-6
CABLE PROCESSOR START (to ME3 Connector)	9261046	3-6
CABLE RA-PROC	9261166	3-6
CABLE TUNNEL SENSOR long	9261066	3-6
CABLE TUNNEL SENSOR short	9261056	3-6
CARRIAGE FRAME	9260846	1-1
CARRIAGE GUIDE	9260076	1-3
CIRCLIP	4500526	1-2, 1-3, 1-4, 2-1, 2-2, 4-1
CIRCLIP	4500566	2-1
CLUTCH DISK	9260606	1-1
CLUTCH DISK ASSY	9260546	1-2
CLUTCH MOUNT ASSY LEFT	9260516	1-2
CLUTCH MOUNT ASSY RIGHT	9260506	1-2
CLUTCH SPRING	9260696	1-2
COUNTERSUNK SCREW	4283521	1-1
COUNTERSUNK SCREW M4 x 12	4282261	2-1, 5-1
COVER PLATE (for M6B and M6AW only)	9261551	4-1
DFT TOP COVER	9263316	5-1
DRIVE GEAR	9216111	2-2
DRIVE GEAR	9260026	1-4
DRIVE GEAR	9260661	1-2

PART NAME	PART No.	FIGURE No.
DRIVE GEAR	9260666	1-4
ENTRANCE GUIDE	9260126	2-1
EXIT GUIDE	9260246	2-1
EXIT ROLLER	9260196	2-1
FAN	9261196	3-6
FILM GUIDE	9250546	1-1
FILM POSITIONER ASSY LEFT	9260926	1-1
FILM POSITIONER ASSY RIGHT	9260916	1-1
FRAME	9260106	2-1
FREE RUNNING CLUTCH	9226130	1-2
FUSE 2.A SLOW BLOW UL/CSA	4539881	3-6
FUSE 3.15A T IEC	4516096	3-6
FUSE F1 F4 T1.6A	4538511	3-1
FUSE F2 F3 T2.5 A	4538501	3-1
GUIDE	9260566	2-1
HANDLE	9262796	2-1
IEC CONNECTOR with FUSE ASSEMBLY	9261186	3-6
INPUT ROLLER BOTTOM	9263016	2-1
INPUT ROLLER TOP	9263026	2-1
KEY	9260701	1-2
KEY 2x2x12	9260671	1-4
KNOB	9260766	4-1
LED GREEN/RED	9250186	3-5
LOCK PLATE	9263371	5-1
LOWER CARRIAGE GUIDE ROLLER, eccentric	9266168	1-6
MAIN SWITCH EXTENSION	9260776	4-1
MOTOR M1	9218016	1-5
MOTOR MOUNTING BRACKET	9260626	1-4
MOUNTING BRACKET LEFT	9260876	1-3
MOUNTING BRACKET RIGHT	9260886	1-3
MOUNTING PLATE	9260046	2-1
NUT M4	4853236	2-1
NUT M4	4853256	1-5
PCB A1 POWER SUPPLY	9261010	3-1
PCB A2 RELAY BOARD	9261020	3-2
PCB A3 SLAVE PROCESSOR without software	9218510	3-3
PCB A4 FTS INTERFACE	9261000	3-4
PERMANENT MAGNET	9263066	3-5, 5-1
PHOTO SENSOR	9261646	1-3
PIN	4796376	1-4, 2-2
PIN	5559519	1-1
P N 5x14	4719346	1-5
PIN ASSY	9229630	5-1

PART NAME	PART No.	FIGURE No.
PLASTIC BEARING	9212051	4-1
PLASTIC BEARING	9222050	2-1
POWER CORD AUSTRALIA	6217861	3-6
POWER CORD ENGLAND / IRELAND	6217851	3-6
POWER CORD FRANCE / ITALY	6004060	3-6
POWER CORD REST OF EUROPE	4513990	3-6
POWER CORD SWIZERLAND	6037200	3-6
POWER CORD US / CANADA / MEXICO	6051531	3-6
PRESSURE ROLLER	9260816	1-1
PRESSURE SPRING front left and back right	9260286	1-1
PRESSURE SPRING front right and back left	9260741	1-1
PULLEY	9211836	1-5
PULLEY WITH BEARING	9260736	1-5
PULLEY with FREE RUNNING CLUTCH	9226130	2-1
RECTIFIER	4522331	3-1
REED SWITCH	9263056	3-5, 5-1
REFLECTIVE FOIL	9189546	1-7
RETAINING RING	4500416	1-5
ROLLER SHAFT	9260826	1-1
ROLLER with O-RING	9260276	1-1
SBS COVER	9261546	6-1
SCREW M3 x 16	4282791	1-3
SCREW M3 x 6	4283286	5-1
SCREW M3 x 8	4283301	1-3, 1-4, 2-1, 2-2
SCREW M4 x 10	4283126	1-1, 1-2, 1-4, 1-5, 2-1, 5-1
SCREW M4 x 20	4282811	1-5
SCREW M4 x 25	4266540	1-2
SCREW M6	4281931	5-1
SECURING PLATE	9261511	2-1
SENSOR	9260226	2-1
SENSOR ACTUATOR LEFT	9260966	1-1
SENSOR ACTUATOR RIGHT	9260956	1-1
SENSOR B1	9228980	3-5
SENSOR BRACKET	9260976	1-3
SERVICE BUTTON	9261376	3-5
SERVICE PLATE	9261506	1-7
SHAFT	9260156	2-1
SHAFT	9260576	1-4
SIDE PANEL large	9263116	6-1
SIDE PANEL small	9263096	6-1
SOFTWARE V 1.3	9263006	3-3
SOLENOID	9224410	5-1
SPACER	8317366	1-1

PART NAME	PART No.	FIGURE No.
SPACER SHAFT	9260856	1-1
SPRING DISK	9260586	1-2
STEPPER MOTOR M2	9250176	1-4
STEPPER MOTOR M3	9250176	2-2
TENSION SPRING	9260336	1-3
THREADED SHAFT	9260721	1-5
TIMING BELT	9260866	1-5
TIMING BELT TENSIONER	9260616	1-5
TOOTHED BELT	9223400	1-4
TOOTHED BELT	9260131	2-1
TOOTHED BELT	9260716	1-2
TRANSFORMER	9267616	3-1
UPPER CARRIGE GUIDE ROLLER	9266166	1-6
WASHER	4470106	1-3
WASHER	4480032	2-1
WASHER	4480036	1-4
WASHER	4480091	1-1
WASHER	4480176	1-3
WASHER	4880036	1-5
WASHER	8317366	2-1
WASHER 3.2	4470106	1-4
WHITE PLASTIC BEARING	9212331	1-2, 1-4

CUSTOMER EQUIPMENT SERVICES KODAK AG STUTTGART GERMANY